

Work Permit # <u>DRL-2014-09/SS-2014-</u> Work Order

If using the permit when all hazard ratings are low, only the following need to sign: (

(Department/Division, or their equivalent, Sup/WCC/Designee)

Date:

Date:

Date:

Although allowed, there is no need to use back of form)

WCC:

Service Provider:

Authorization to start

Job# Activity# See "Instructions for Filling out the Work Permit" contained in the Work Planning and Control for Experiments and Operations Subject Area. 1. Work request WCC fills out this section. ☐ Standing Work Permit Dept/Div/Group: PO/PHENIX Requester: Don Lynch Date: 6/27/2014 Ext.: 2253 Other Contact person (if different from requester): Carter Biggs Ext.: 7515 Start Date: 7/7/2014 Est. End Date: 11/30/2014 Work Control Coordinator: Don Lynch Brief Description of Work: Mechanical assembly and Installation of MPC-Ex Detector subsystem (North and South) Room: IR Equipment: MPC-Ex Service Provider: PHENIX technicians and MPC-Ex experts Building: 1008 2. WCC, Requester/Designee, Service Provider, and ESS&H (as necessary) fill out this section or attach analysis **ESS&H ANALYSIS Radiation Concerns** None ☐ Activation ☐ Airborne ☐ Contamination Radiation ☐ Other ☐ Special nuclear materials involved, notify Isotope Special Materials Group Fissionable/Radiological materials involved, notify Laboratory Nuclear Safety Officer Soil Density Gauges Radiation Generating Devices: Radiography ☐ Moisture Density Gauges X-ray Equipment ☐ Transport of Haz/Rad Material ☐ Pressurized Systems **Safety and Security Concerns** ☐ None ☐ Explosives ☐ Critical Lift ☐ Adding/Removing Walls or Roofs ☐ Fumes/Mist/Dust* ☐ Magnetic Fields* ☐ Railroad Work ☐ Asbestos* ☐ Cryogenic ☐ Heat/Cold Stress ■ Nanomaterials/particles* □ Rigging ☐ Beryllium* ☐ Electrical ☐ Hydraulic ☐ Noise* ☐ Silica* ☐ Biohazard* ☐ Lasers* ■ Non-ionizing Radiation* ☐ Security Concerns ☐ Excavation ☐ Chemicals/Corrosives* ☐ Lead* ☐ Oxygen Deficiency* ☐ Suspect/Counterfeit Items Material Handling ☐ Confined Space* ☐ Ergonomics* ☐ Penetrating Fire Walls ☐ Vacuum Haz. Rad. Bio Material Exceed DOE 151.1-C Levels - Contact OEM * Safety Health Rep. Review Required ○ Other: work near beampipe None ☐ Work impacts Environmental Permit No. **Environmental Concerns** ☐ Land Use Institutional ☐ Soil Activation/contamination ☐ Atmospheric Discharges (rad/non-rad) ☐ Waste-Mixed Controls ☐ Chemical or Rad Material Storage or Use ☐ Liquid Discharges ☐ Waste-Clean ■ Waste-Radioactive Cesspools (UIC) ☐ Oil/PCB Management ☐ Waste-Hazardous ☐ Waste-Regulated Medical ☐ High water/power consumption ☐ Spill potential ☐ Waste-Industrial ☐ Underground Duct/Piping Waste disposition by: ☐ Other Pollution Prevention (P2)/Waste Minimization Opportunity: No □ Yes **FACILITY CONCERNS** ☐ Intermittent Energy Release ☐ Vibrations ☐ Electrical Noise ☐ Potential to Cause a False Alarm ☐ Access/Egress Limitations ☐ Impacts Facility Use Agreement Other ☐ Temperature Change ☐ Configuration Management ☐ Maintenance Work on Ventilation Systems ☐ Utility Interruptions WORK CONTROLS **Work Practices** ☐ None ☐ Exhaust Ventilation ☐ Spill Containment ☐ Security (see Instruction Sheet) □ Back-up Person/Watch ☐ HP Coverage ☐ Posting/Warning Signs ☐ Time Limitation Other ☐ Warning Alarm (i.e. "high level") ☐ Barricades ☐ IH Survey Scaffolding-requires inspection ☐ Electrical Inspection Required **Personal Protective Equipment** ☐ None ☐ Ear Plugs ☐ Gloves as appropriate ☐ Lab Coat □ Safety Glasses as appropriate ☐ Coveralls ☐ Ear Muffs ☐ Goggles ☐ Respirator* ☐ Safety Harness Safety Shoes as ☐ Other ☐ Disposable Clothing ☐ Face Shield ☐ Hard Hat ☐ Shoe Covers ☐ High visibility cloths/vest appropriate Permits Required (Permits must be valid when job is scheduled.) ☐ Cutting/Welding ☐ Impair Fire Protection Systems None ☐ Digging/Core ☐ Rad Work Permit-RWP No ☐ Concrete/Masonry Penetration Drilling ☐ Electrical Working ☐ Confined Space Entry ☐ Other Dosimetry/Monitoring ☐ Heat Stress Monitor ☐ Real Time Monitor □ TLD None ☐ Air Effluent ☐ Noise Survey/Dosimeter ☐ Self-reading Pencil Dosimeter ☐ Waste Characterization O₂/Combustible Gas ☐ Ground Water ☐ Self-reading Digital Dosimeter ☐ Other ☐ Liquid Effluent ☐ Passive Vapor Monitor ☐ Sorbent Tube/Filter Pump Training Requirements (List specific training requirements) PHENIX Awareness, CA Access or Equiv. Scaffold Training,

7.0/3k11e011.doc 1 (09/2011)

☐ High

☐ High

☐ High

Based on analysis above, the Review Team determines the risk, complexity, and

⊠ Low

□ Low

□ Low

Moderate Moderate

☐ Moderate

coordination ratings below:

ESS&H Risk Level:

Complexity Level:

Work Coordination:

		ork plan (use attachments for detailed			
Work Plan (procedures, timing, equip	ment, scheduling, coordination, no	tifications, and personnel availability need to be	e addressed in adequate detail): Se	ee attached Procedure.	
Special Working Conditions Required	(e.g., Industrial Hygiene hold point	s or other monitoring)			
None					
Notifications to operations and Opera	tional Limits Requirements: None				
Post Work Testing, Notification or Doo	· · · · · · · · · · · · · · · · · · ·				
Job Safety Analysis Required: Y	·	Review Done: 🛛 in seri	an D toom		
Job Galety Allalysis Nequiled.	55 M NO	Neview Dolle. 🖂 III Sell	es 🔲 team		
Reviewed by: * Primary Reviewer sig	anature means that the Review Tea	m members were appropriate for the work that	was planned the Team visited the	ioh site hazards and risks	
that could impact ESS&H have been	considered and controls established	d according to BNL requirements. In addition, t	his signature indicates that applica		
1 0		s have been identified and recorded on this per		T.,	
<u>Title</u>	Name (print)	<u>Signature</u>	Life #	Date	
ES&H Professional					
F&O Facility Project Manager					
Service Provider					
Work Control Coordinator	Don Lynch		20146		
Safety Health Representative					
Research Space Manager					
Other					
Other (PHENIX Escort)					
Required Walkdown Completed					
*Primary Reviewer					
<u>·</u>			<u> </u>		
4. Job site personnel (Supervis		section. erstand the hazards and permit requirements (including any attachments) and all	training required for this	
permit is current/complete. Job Supe	rvisor/Contractor Supervisor signat	ures also includes verification that worker traini	ng required for this permit is curren	it/complete.	
Job Supervisor:		Contractor Supervisor:	Contractor Supervisor:		
Workers: Life#:		Workers:	Life#:	Life#:	
Workers are encouraged to provide fe	edback on ESS&H concerns or on	ideas for improved job work flow. Use feedbac	ck form or space below.		
5. Department/Division, or the	ir equivalent, Line Manager	or Designee			
Conditions are appropriate to start wo	rk: (Permit has been reviewed, wo	rk controls are in place and site is ready for job	.)		
Name:	Signature:	Life#:	Date:		
C Marker provides feedback					
Worker provides feedback.Worker Feedback (use attached she	eets as necessary)				
·	••				
a) WCM/WCC: Are there a	ny changes as a result of worker fe	edback? LI Yes LI No			
Note: See Work Planning and Control					
		uthorizing dept.) checks quality of com the to work supervisor.) The WCC ensure			
postings, procedures, etc., is initia		e to work supervisor.) The WOO ensure	es that the change process to t	ipuate drawings, placards	
Name:	Signature:	Life#:	Date:		
Comments:			'		

MPC-Ex

Introduction

The Muon Piston Calorimeter (MPC) Extension, or MPC-EX, is a Si-W preshower detector that will be installed in front of the existing PHENIX MPC's in both the north and the south Muon Magnets. This detector consists of eight layers of Si "minipad" sensors interleaved with tungsten absorber and enables the identification and reconstruction of $\pi 0$ mesons at energies up to ~ 80 GeV.

The PHENIX Collaboration will install this new detector subsystem during the 2014 summer shutdown to be fully ready for service for run 15. An engineering run consisting of a partial detector installed in the south Muon Magnet piston hole was successfully implemented for run 14, proving and qualifying the detector installation techniques and operational characteristics. This document describes the work plan to assemble and install the full complement of 2 stations (north and south) for the detector.

MPC-Ex Design

(Please see the attached Assembly and Installation Plan for illustrations of the following design, assembly and installation descriptions.)

The MPC-Ex design consists of 8 layers (plates) of 2.0 mm thick tungsten spaced 4.5 mm apart. There are upper and lower halves to the MPC-Ex and north and south stations in the north and south Muon Magnets, respectively. On to each tungsten plate a carrier board is adhered. To each carrier board 12 micromodules consisting of a minipad silicon sensor sandwiched and glued between a ceramic base and a Dual SVX-4 Readout Card. The card is then wirebonded to the silicon sensor. On the side farthest from the PHENIX IP, a Delrin plate will be attached provide a light tight closure beyond the last layer of carrier board.

Assembly of the MPC-Ex detectors requires gluing fixtures for the micromodules and for the carrier board/tungsten plate lamination.

The 8 layers are stacked up and spaced using threaded rods and threaded spacers, then the upper and lower ends are capped with support covers. Low voltage distribution boards are mechanically attached to the upper and lower support covers. Each Carrier board has power connections between itself and the LV distribution board and bias voltage connections. The LV distribution boards have power and communication cables to a control racks mounted on the north and south MuTrigger racks.

In addition, each carrier board has 2 ribbon cable pig tails which connect via a 2 meter ribbon cable to a front end module. The front end module in turn connects back to the

control rack via flat LVDS cable. Communication from the rack room to the MPC-Ex control racks will be via fiber optic cables.

Cooling for the MPC-Ex will be accomplished using the PHENIX dry air system, which is already providing cooling for the MPC detectors.

In order to accommodate the MPC-Ex, minor modifications to existing equipment is required as follows:

- 1. The "bellows spreader" which prevents lateral and twisting movement of the bellows in the south Muon Magnet (MMS) (while allowing unimpeded longitudinal movement) will be removed and replaced with a new design which has a smaller radial footprint to allow maximization of detector coverage. This new design is referred to as an "anti-squirm" device to more accurately describe its function. (Note: there is no bellows spreader in the north Muon Magnet [MMN], and as such no anti-squirm device is required i the north magnet.
- 2. Light collection boxes for the existing MPC's will be moved to the MuID station 1 front end electronics plate (FEE plate) on both north and south detector stations. MuID cables and components on the FEE plate will be relocated / rerouted as necessary to accommodate the light collection boxes.
- 3. MPC Fiber optic extensions and adapters will be fabricated to allow the light box relocations.
- 4. Other minor modifications on the side panels of the MMS and MMN to accommodate mounting of MPC-Ex Front End modules will be undertaken as necessary.

Mounting clips are designed to attach to the walls of the MMS and MMN piston cavities to precisely locate the MPC-Ex in the piston holes. Mating mounting tabs are designed for the multiple purposes of aligning and attaching the 2 halves of the detectors to each other around the beam pipe, guiding the insertion of the MPC-Ex detector into the piston holes and precisely positioning the MPC-Ex's in the piston holes.

Installation of the MPC-Ex detectors will require scaffolding, a custom designed insertion/installation tool, and a rigging fixture to lift the upper and lower halves onto the insertion/installation tool.

Assembly Procedures

Micromodule Assembly

Using the micromodule gluing fixture:

- 1. Lay the ceramic sheet on a clean flat granite table
- 2. apply appropriately sized kapton tape to the table precisely around the edges of the ceramic sheet to define the gluing surface.
- 3. apply glue to the ceramic sheet and squeegee to achieve precise thickness
- 4. lay the silicon sensor sheet on the table and similarly mask and apply glue to the sensor, except on the end where the wire bonding pads are, place the tape over the bonding pads to prevent adhesive from sticking to the pads.
- 5. position the ceramic sheet in the vacuum gluing fixture base then turn on vacuum to hold part in place
- 6. place the silicon sensor on the glue laden ceramic sheet, leaving the tape on the wire bond pads and carefully positioning the sensor to align precisely with the ceramic.
- 7. place the SVX-4 readout card on the silicon sheet on the glue carefully positioning the card to align precisely with the sensor and ceramic.
- 8. position the slotted micromodule glue fixture side lock on the base and slide it to align the SVX-4 board to the ceramic and sensor sheets, then lock it in position with the thumb screws (finger tight only)
- 9. Place the gluing fixture weight distributor top on the readout card being careful not to shift the stack.
- 10. Place 2 20-lb bricks on top of weight distributor gluing fixture top cap).
- 11. Let sit for 30 minutes, then loosen and remove slotted side lock.
- 12. Carefully peal the kapton tape off the sensor wire bonding pads.
- 13. Let the weighted assembly sit for at least 8 hours to allow adhesive to completely set.
- 14. Remove micromodule from gluing fixture.
- 15. Inspect for imperfections in stack and/or gluing
- 16. Send micromodule with vacuum base to instrumentation for wirebonding.
- 17. Acceptance test

Carrier Board/Tungsten Lamination Assembly

- 1. Place tungsten plate in laminating fixture on flat granite table
- 2. Apply double-sided thermal conductive adhesive tape to entire upper surface of tungsten plate
- 3. Peel off double-sided tape backing and make sure adhesive is distributed to all edges
- 4. Carefully position carrier board on adhesive covered side of tungsten plate

- 5. Place 1/4 inch (minimum) anti-static foam on top of carrier board, then place a 1 inch thick steel plate at least large enough to cover the entire area of the the carrier board. (~40 lbs weight)
- 6. Let stand for at least 1 hour for adhesive to set.
- 7. Inspect for imperfections in lamination
- 8. Acceptance test

MPC-Ex Detector Final Assembly

Assemble Upper and Lower halves of MPC-Ex in accordance with MPC-Ex Assembly drawing (drawing # 105-0219-119 attached). (worker planned work).

MPC-Ex Detector Installation

(Note: Scaffolding for installation of MPC-Ex was designed and installed for Muon Tracker work in previous and current shutdowns. Design and installation including all appropriate approval paperwork is provided in the current work permit # DRL-2014-10/SS-2013-___ Muon Tracker Station 1 North & South Maintenance and Repair.)

Removal of the Run 14 Partial Installation

The partial detector MPC-Ex installed for an engineering run during Run 14 will be uninstalled and removed by reversing the installation sequence described below for the 2 full stations of the detector. Although only partially instrumented, the partial detector is geometrically the same as the full detector. After MPC-Ex run 14 partial installation has been removed, disassemble the station 1 scaffolding in accordance with WP #DRL-2014-10 move the CM south to open station 1 north in accordance with standard PHENIX procedure PP-2.5.5.1-01, then install the station 1 scaffolding in north station 1.

MPC-Ex North Station

- 1. Affix temporary beampipe support to beampipe in station 1
- 2. Remove existing beampipe support
- 3. Remove and relocate MPC light collection boxes
- 4. Install fiber extensions using fabricated fiber connectors and holders provided
- 5. Drill and tap mounting holes for MPC-Ex mounting clips
- 6. Install MPC-Ex insertion/installation tool
- 7. Install mounting clips

- 8. Using MPC-Ex lifting fixture, install upper and lower MPC-Ex detector halves on insertion/installation device with mount mounting tabs
- 9. Install MPC-Ex into piston hole.
- 10. Install front end module(s) on magnet sides.
- 11. Route cables, fibers and cooling lines as necessary
- 12. Test and commission partial new detector
- 13. Remove station 1 scaffolding
- 14. restore CM to run position in accordance with PHENIX Procedure PP-2.5.5.1-01


MPC-Ex South Station


- 1. Affix temporary beampipe support to beampipe in station 1
- 2. Remove existing "bellows spreader"
- 3. Install new anti-squirm device
- 4. Remove and relocate MPC light collection boxes
- 5. Install fiber extensions using fabricated fiber connectors and holders provided
- 6. Drill and tap mounting holes for MPC-Ex mounting clips
- 7. Install MPC-Ex insertion/installation tool
- 8. Install mounting clips
- 9. Using MPC-Ex lifting fixture, install upper and lower MPC-Ex detector halves on insertion/installation device with mount mounting tabs
- 10. Install MPC-Ex into piston hole.
- 11. Install front end module(s) on magnet sides.
- 12. Route cables, fibers and cooling lines as necessary
- 13. Test and commission partial new detector
- 14. Remove station 1 scaffolding
- 15. restore MMS to run position in accordance with PHENIX procedure PP-2.5.5.1-01

Closeout

After installation is complete, document and record any lessons learned in this initial installation. Sign and close out the MPC-Ex work permit and the Muon Tracker Station 1 south work permit (for scaffold use).

MPC-Ex Assembly and Installation Plan







June - November, 2014 Don Lynch

1

Current Plan for Full MPC-Ex Installation for Run 15

For Run-15 the goal will be to install complete MPC-EX detectors in both the north and south muon magnet piston. All layers will be fully populated with sensors and electronics and both stations will be fully operational .


Subassemlies:

ROC Micro-modules: There are normally 12 of these for each half layer, 392 total for both MPC-Ex's. All will be included in the Run 15 installation. Each ROC micro-module is assembled as a PC board, a silicon sensor module and a ceramic sheet which are all glued together in a gluing fixture. The sensor is then sent to instrumentation to have its sensor leads wire bonded to the electrical distribution pads on the PC board.

Carrier boards: Produced outside.


Tungsten/Carrier board modules: The carrier boards are fastened to 2mm thick tungsten plates at PHYSICS using a positioning fixture and double sided adhesive.

Upper and Lower, North and South Detector segment assemblies are then mechanically assembled. Each is made of 8 T/C modules and a single Delrin cover plate (design identical to tungsten plates). The space between tungsten plates is made uniform by threaded spacers and the entire assembly is held together with threaded rods on which the spacers ride. The top and bottom modules have their upper and lower ends protected by a Delrin "cradle" which provides extra support, protection for the signal cables and support for the power supply/PC interface boards.




Micromodule layout

FECHZHUAL SUPPORT NO14













Micromodule Gluing tool micromodule parts and glued assembly currently in production $% \left(1\right) =\left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left(1\right) \left(1\right) +\left(1\right) \left(1\right)$











MPC-Ex Full Model


Run 14 Partial installation will include $\frac{1}{4}$ of the electronics and all of the tungsten for the south detector. Edge closures not shown.




MPC-Ex Site Preparation



Insertion/installation tool installed with beampipe protection




Scaffolding in place from MuTr maintenance




Front end electronics enclosures mounted on existing MuTrigger front end electronics boxes.

MPC Flat cables replaced with round cables (Done last year)


MPC Cables rerouted





MPC-Ex mockup to be used for cable and utilities routing plans













 $1^{\rm st}$ test of front end module board with laminated tungsten/carrier board & partial micromodules


PH^{*}ENIX

THUTZHUAL SUPPORT NO14


INSTALLATION









Upper and lower MPC-Ex halves with lifting tools for positioniong halves around beampipe on insertion/lifting tool







MPC-EX

Power Distribution



Power Requirements (One Side)

- Detector split into upper and lower portions with 8 SVX boards each.
- Each portion monitored and controlled by one 8 channel MPC-EX LV Distribution Controller.
- Each channel (SVX board) requires:
- 1. 2.5V @ 2A Analog
- 2. 2.5V @ 1A Digital
- 3. 1.5V @ 0.2A Digital
- 4. 3.3V @ 0.2A Config




MPC-EX LV Distribution Board

- Fed by LV and bias from rack mounted power supplies.
- All channels fused by polyswitches.
- 8 channels of bias passively routed to SVX boards.
- Computer controlled via RS485 link from PC:
- Individual channel LV enables.
- 2. Temperature monitoring of LV Dist and SVX boards.
- 3. Voltage monitoring of higher current outputs.



MPC-EX LV Distribution Board



MPC-EX LV Distribution Board

TE Mate-N-Lok




JST PHD Connector



MPC-EX Racks

- •Same 1m x 1m type as MPC with 31" of vertical rack space.
- •Mounted on top of SMT5 and NMT5 racks.
- •Contain low voltage, NIM crate and bias.

SMT₅





Cables, Connectors and Fuses

- Low voltage:
 - Alpha 65205 AWG #12 fused at the source for 15A.
 - TE 640583-3 Mate-N-Lok LV Distribution Board input connector.
 - JST PHD connector, 250V rated, UL94V-0 output channel connector, polyfused for 4A or less.
- Bias voltage:
 - AWG #26 300V rated instrumentation cable.
 - JST PHD connector, 250V rated, UL94V-o.

Pink/White/Blue Sheets

Installation Schedule

Procure & Fabricate parts for MPC-Ex North and South 1/1/2014-6/30/2014 Start of Shutdown Tasks (purge flammable gas, disassemble and stow shield wall, remove collars, move EC to AH, Move MMS south, etc.) 7/14 - 7/25/2014 Install scaffolding in Sta 1 South 7/28/2014 Remove MPC-Ex prototype 7/28-8/1/2014 MuTr Sta 1 South troubleshooting and repairs 7/28-8/1/2014 Maint. & Repairs for MPC South, BBC South, RPC1 South1 7/28-8/1/2014 Assemble & test MPC-Ex North, ready for installation 8/1-9/5/2014 8/4-8/5/2014 Remove scaffolding from sta 1 south, Move CM South Install scaffolding in Sta 1 North 8/6-8/8/2014 MuTr Sta 1 & Sta. North troubleshooting and repairs 8/11-9/5/2014 Prep MPC-Ex North installation area 8/11-9/5/2014 9/8-9/26/2014 Install new MPC-Ex North Assemble & test MPC-Ex South, ready for installation 9/2-10/3/2014 Remove Sta 1 N scaffolds, Move CM North, Install scaffolding in Sta 1 S 9/29-10/3/2014 Install MPC-Ex South 10/6-10/24/2014 End of Shutdown Tasks (Move MS north, roll in EC, install collars, remove 10 ton cart, plates and manlifts, build shield wall, etc.) 10/27-11/26/2014 MPC-Ex Pre-Run Commissioing 10/27-12/31/2014

Start Flammable gas flow ?????
Close shield wall, install radiation interlocks and prepare for run 14 12/31/2014
Start run 15 1/2/2015

12/1-12/19/2014

